



**WEYERMANN® SPECIALTY
MALTING COMPANY**

Andreas Richter—Quality Manager
Brennerstraße 17-19 D-96052 Bamberg, Germany
phone: +49-951-93-22-0-22 fax: +49-951- 93220 - 922
andreas.richter@weyermann.de www.weyermann.de



Weyermann® Liquid Malt Extract (LME) is a pure, adjunct-free, unhopped extract made in our own brewery exclusively from genuine Weyermann® base and specialty malts. Undiluted Weyermann® LME has a malt concentration of 72 – 79% (OG 1.350 – 1.400), which makes it ideally suited for both home-brewed and craft-brewed beers, as well as for yeast starters.

We ship our LME in sterile plastic jerry cans of 4 kg (8.8 lbs).
It has a shelf life of 18 months if stored cool.

Mix Weyermann® LME using the table below. Note that values apply to all LME varieties. First, select the desired wort gravity in one of the two left columns. Then, from the corresponding row, calculate the required amount of Weyermann® LME malt extract for the desired wort volume by using the value in metric or English units that is appropriate for your system.

Add bittering hops at the beginning of the boil and measure wort gravity at the end of the boil. To compensate for insufficient or excessive evaporation losses, extend the boil or liquor down the wort.

% extract @ end of boil in °P	OG	Extract-to-liquor ratio by weight	Extract in U.S lbs. per 1 U.S. gallon of wort	Extract in U.S lbs. per 1 U.S. barrel of wort	Extract in grams per 1 liter of wort	Extract in liters per 1 hectoliter of wort
8	1.032	1/8.5	0.88	27.2	105	7.3
8.5	1.034	1/7.9	0.93	29	112	7.8
9.0	1.036	1/7.4	0.98	30.5	118	8.2
9.5	1.038	1/7.0	1.04	32.3	125	8.7
10	1.040	1/6.6	1.1	34.1	132	9.2
10.5	1.042	1/6.2	1.15	35.7	138	9.6
11.0	1.044	1/5.9	1.2	37.5	145	10.1
11.5	1.046	1/5.6	1.26	39.1	151	10.5
12	1.048	1/5.3	1.32	40.9	158	11
12.5	1.050	1/5.1	1.37	42.4	164	11.4
13	1.052	1/4.8	1.43	44.2	171	11.9
13.5	1.054	1/4.6	1.5	46	178	12.4
14	1.056	1/4.4	1.54	47.6	184	12.8
14.5	1.058	1/4.2	1.59	49.4	191	13.3
15	1.060	1/4.1	1.64	51	197	13.7
15.5	1.060	1/3.9	1.70	52.8	204	14.2
16	1.062	13.8	1.76	54.6	211	14.7
16.5	1.064	1/3.6	1.81	56.1	217	15.1
17	1.066	1/3.5	1.87	58	224	15.6

Address all inquiries to andreas.richter@weyermann.de
or call +49-951-93220-22